

## New car applications

	from	up to	Manual/ Autom.	ABS ring	Remarks	Spidan	Description	left/ right	front/ rear	outer	inner	pic.	Technical Specifications
<b>CITROEN</b>													
<b>C8</b>													
2.2 (116 kW)	07.02 -		MT/AT		TPE boot	<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97
2.0 HDi (79/94 kW)	07.02 -		MT/AT		TPE boot	<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97
<b>EVASION (22, U6)</b>													
1.8 (73 kW)	05.97 -	07.02	MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48 L:112/Ø1=25.5/Ø2=84.5 L:96/Ø1=25.5/Ø2=70 (for tripod joint)
			MT			<b>24540</b>	Boot Kit			x			
			MT			<b>24552</b>	Boot Kit				x		
2.0 (89 kW)	06.94 -	07.02	MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48 L:112/Ø1=25.5/Ø2=84.5 L:96/Ø1=25.5/Ø2=70 (for tripod joint)
			MT			<b>24540</b>	Boot Kit			x			
			MT			<b>24552</b>	Boot Kit				x		
2.0 16V (97 kW)	05.98 -	04.00	MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48 L:112/Ø1=25.5/Ø2=84.5 L:96/Ø1=25.5/Ø2=70 (for tripod joint)
			MT			<b>24540</b>	Boot Kit			x			
			MT			<b>24552</b>	Boot Kit				x		
2.0 16V (100 kW)	05.00 -	07.02	MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48 L:112/Ø1=25.5/Ø2=84.5 L:96/Ø1=25.5/Ø2=70 (for tripod joint)
			MT			<b>24540</b>	Boot Kit			x			
			MT			<b>24552</b>	Boot Kit				x		
2.0 Turbo C.T. (108 kW)	06.94 -	07.02	MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48 L:113/Ø1=29.3/Ø2=92
			MT			<b>24544</b>	Boot Kit			x			
1.9 TD (66 kW)	11.94 -	07.02	MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48 L:113/Ø1=29.3/Ø2=92
			MT			<b>24544</b>	Boot Kit			x			
2.0 TD (68 kW)	05.97 -	07.02	MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48 L:113/Ø1=29.3/Ø2=92
			MT			<b>24544</b>	Boot Kit			x			
2.0 HDI (80 kW)	08.99 -	07.02	MT	x	TPE boot	<b>24545</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48 L:112/Ø1=29/Ø2=97
			MT			<b>24546</b>	Boot Kit			x			
2.1 TD (80 kW)	05.96 -	07.02	MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48 L:113/Ø1=29.3/Ø2=92
			MT			<b>24544</b>	Boot Kit			x			
<b>JUMPY (U6U) / JUMPY VAN</b>													
1.6 / 1.6 i (58 kW)	10.95 -		MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48 L:112/Ø1=25.5/Ø2=84.5 L:96/Ø1=25.5/Ø2=70 (for tripod joint)
			MT			<b>24540</b>	Boot Kit			x			
			MT			<b>24552</b>	Boot Kit				x		

	from	up to	Manual/ Autom.	ABS ring	Remarks	Spidan	Description	left/ right	front/ rear	outer	inner	pic.	Technical Specifications
2.0 (100 kW)	04.00 -	12.06	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 i 16V (102 kW)	03.00 -		MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
1.9 D (51 kW)	10.95 -		MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
1.9 TD (66/68 kW)	10.95 -		MT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
2.0 HDi (69/80 kW)	10.99 -		MT	x	TPE boot	24545	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24546	Boot Kit			x			L:112/Ø1=29/Ø2=97

## FIAT

### SCUDO (220P/220L)

1.6 (58 kW)	02.96 -		MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 16V (100 kW)	06.00 -		MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
1.9 D (51 kW)	02.96 -		MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
1.9 TD (66/68 kW)	02.96 -		MT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
1.9 TD Eco (66 kW)	02.96 -		MT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
2.0 JTD (69/80 kW)	12.99 -		MT	x	TPE boot	24545	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24546	Boot Kit			x			L:112/Ø1=29/Ø2=97

### ULYSSE (220)

1.8 (73 kW)	05.97 -	08.02	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)

	from	up to	Manual/ Autom.	ABS ring	Remarks	Spidan	Description	left/ right	front/ rear	outer	inner	pic.	Technical Specifications
2.0 (89 kW)	06.94 -	08.02	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 / 2.0 16V (97/100 kW)	05.98 -		MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 Turbo (108 kW)	06.94 -	08.02	MT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
1.9 TD (66 kW)	02.95 -	08.02	MT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
2.0 JTD (80 kW)	10.99 -	08.02	MT	x	TPE boot	24545	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24546	Boot Kit			x			L:112/Ø1=29/Ø2=97
2.1 TD (80 kW)	03.96 -	10.99	MT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92

## LANCIA

### ZETA (220)

2.0 16V (97/100 kW)	05.98 -	09.02	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 Turbo (108 kW)	05.95 -	09.02	MT/AT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT/AT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
2.0 JTD (80 kW)	10.99 -	09.02	MT	x	TPE boot	24545	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			24546	Boot Kit			x			L:112/Ø1=29/Ø2=97
2.1 TD (80 kW)	05.96 -	09.99	MT/AT	x	TPE boot	24543	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT/AT			24544	Boot Kit			x			L:113/Ø1=29.3/Ø2=92

## PEUGEOT

### 806

1.8 (73 kW)	07.95 -	08.02	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 (89 kW)	06.94 -	08.02	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 16V (97 kW)	05.98 -	08.02	MT	x	TPE boot	24526	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			24540	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			24552	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)

	from	up to	Manual/ Autom.	ABS ring	Remarks	Spidan	Description	left/ right	front/ rear	outer	inner	pic.	Technical Specifications
2.0 16V (100 kW)	05.98 -	08.02	MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			<b>24540</b>	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			<b>24552</b>	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 Turbo (108 kW)	06.94 -	08.02	MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			<b>24544</b>	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
1.9 TD (66/68 kW)	07.95 -	08.02	MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			<b>24544</b>	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
2.0 HDI (80 kW)	08.99 -	08.02	MT	x	TPE boot	<b>24545</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97
2.1 td 12V (80 kW)	06.96 -	08.99	MT/AT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT/AT			<b>24544</b>	Boot Kit			x			L:113/Ø1=29.3/Ø2=92

### 807

2.2 (116 kW)	06.02 -		MT/AT		TPE boot	<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97
3.0 V6 (150 kW)	06.02 -		MT/AT		TPE boot	<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97
2.0 HDI (79 kW)	06.02 -		MT/AT		TPE boot	<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97
2.2 HDI (94 kW)	06.02 -		MT/AT		TPE boot	<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97

### EXPERT (224,222,223)

1.6 (58 kW)	02.96 -		MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			<b>24540</b>	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			<b>24552</b>	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
2.0 (100 kW)	07.00 -		MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			<b>24540</b>	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			<b>24552</b>	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
1.9 D (51 kW)	02.96 -		MT	x	TPE boot	<b>24526</b>	Joint Kit			x		27	A:27/F:34/O.58/X/ABS:48
			MT			<b>24540</b>	Boot Kit			x			L:112/Ø1=25.5/Ø2=84.5
			MT			<b>24552</b>	Boot Kit				x		L:96/Ø1=25.5/Ø2=70 (for tripod joint)
1.9 TD (66/68 kW)	02.96 -		MT	x	TPE boot	<b>24543</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			<b>24544</b>	Boot Kit			x			L:113/Ø1=29.3/Ø2=92
2.0 HDI (69/80 kW)	07.00 -		MT	x	TPE boot	<b>24545</b>	Joint Kit			x		27	A:27/F:39/DF:28.6/O:58/X/ABS:48
			MT			<b>24546</b>	Boot Kit			x			L:112/Ø1=29/Ø2=97

# Newsletter 03/2010

New part nos.

Car Manufacturer	OE *	Spidan	Description	Barcode	Gross weight (kg)	Measurements of		
						Length	Width	Height
CITROEN FIAT LANCIA PEUGEOT	9619947580	24526	Joint Kit	4019064045267	2,4	222	115	110
	9619947680							
	9619947588							
	9619947688							
	9621456388							
	9621456488							
	9626084088	24543	Joint Kit	4019064045434	2,6	222	101	100
	9617408288							
	9617408188							
	1481451080	24545	Joint Kit	4019064045458	2,7	222	115	110
	1481452080							
	32729C							
	3272GY							
	32733Q							
	3273GQ							

\* OE = Driveshaft!

Car Manufacturer	OE	Spidan	Description	Barcode	Gross weight (kg)	Measurements of		
						Length	Width	Height
CITROEN FIAT LANCIA	9645967380	24540	Boot Kit	4019064045403	0,4	168	103	103
	9655377080	24544	Boot Kit	4019064045441	0,33	168	103	103
	329306	24546	Boot Kit	4019064045465	0,35	168	103	103
	9567504880							
	9647779380	24552	Boot Kit	4019064045526	0,425	168	103	103